




How to Clean the Anker 2.4G Wireless Mouse Scroll Wheel

This guide will show you how to properly clean the scroll wheel of an Anker 2.4G wireless mouse.

Written By: Colin






TOOLS:

- [Phillips #0 Screwdriver](#) (1)
 - [Q-Tips](#) (1)
-

Step 1 — How to Clean the Anker 2.4G Wireless Mouse Scroll Wheel



- Use a screwdriver to remove the stickers that are hiding the screws.

Step 2



- Remove 4 screws Phillips #0 screws.

Step 3



- Use a screwdriver to pry along the center seam of the mouse.
- Open the outer casing of the mouse.



Step 4



- Remove the wires from the white crimp headers in order to separate the upper and lower housing units of the mouse.

⚠ Pull the wires as gently as possible to ensure that the wires will not break.

Step 5



- Take a q-tip and lightly remove any dirt or debris around the pin connections of the scroll wheel (circled in red).

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-20 09:16:06 PM.